PATCH & REPAIR PLASTER; SKIMCOAT SURFACE TO ACHIEVE A CLEAN, UNIFORM FINISH

14 A501 REF PHOTO
SCALE NTS



REMOVE EXSTG & INSTALL NEW DOORS AT LOCS WHERE VENEER IS PEELING (TYP 5 LOCS); SPECIES TO MATCH EXSTG (OAK, VIF). SALV & REINSTALL HDW

13 A501 REF PHOTO
SCALE NTS



REMOVE DRAWER ON ETR BASE CAB TO CREATE PULL-OUT WRITING SURFACE AND DRAWER IN SAME LOC. SEE ELEVS & DETAILS FOR ADDT'L INFO

REMOVE, SALV & RETURN TO OWNER BASE CAB BOX AS INDICATED TO CREATE KNEEHOLE; PROTECT ADJ ETR BASE CABS & CHASE

ST-1 ALL DRAWERS & DOORS ETR U.N.O. SALV & REINSTALL HDW. REF TO ELEVS

12 A501 REF PHOTO
SCALE NTS



USE SEGMENTS OF ATTIC STOCK EPOXY TO INFILL AT TROUGH REMOVAL; CONCEAL SEAMS UNDER NEW REAGENT VERT SHELF SUPPORTS &/OR CHASES TO GREATEST EXTENTS POSSIBLE. MIN VISIBLE SEAMS. BUFF & POLISH TO ACHIEVE SMOOTH, CLEAN, CONT FINISH

REMOVE EPOXY TROUGH; PROTECT UTILITY CHASE BELOW.

11 A501 REF PHOTO
SCALE NTS



REMOVE REAGENT SHELF, SUPPORTS, AND POWER SUPPLY; COORD W ELEC

10 A501 REF PHOTO
SCALE NTS



REMOVE EPOXY TROUGH; PROTECT ETR UTILITY CHASE

RETAIN CAB BRACING INSIDE UTILITY CHASE; REMOVE & REINSTALL AS NEEDED FOR BASE CAB DEMOLITION

REMOVE ABANDONED & PROTECT ACTIVE PLMB & ELEC LINES; COORD W MEP

9 A501 REF PHOTO - BENCH A/B UTILITY CHASE
SCALE NTS



REMOVE ABANONDED ACID VENT LINES; GLASS PIPES ENCLOSED BY SS JACKET; COORD W MECH

PROTECT ACTIVE PLMB & ELEC LINES PENETRATING COUNTERTOP; COORD W MEP

8 A501 BENCH A/B UNDER COUNTER REF PHOTO
SCALE NTS



USE EPOXY ATTIC STOCK TO PATCH HOLES IN COUNTERTOP AT ACID VENT STACK REMOVAL

AT BENCH 'A' & 'B' REMOVE 2" OF EXSTG EPOXY COUNTERTOP OFF WESTERNMOST END

REMOVE WOODEN VERT CHASE & ASSOCIATED TRIM AT WEST END OF BENCH

7 A501 BENCH A/B REF PHOTO
SCALE NTS



EXSTG ACID VENT GLASS PIPE WITH SS PIPE JACKET TO REMAIN; PROTECT. CONCEAL IN NEW CHASE CONST; REF TO PLAN DETAIL

REMOVE ABANDONED ACID VENT LINES; 1-½"GLASS PIPES ENCLOSED BY SS JACKET; COORD W MECH. PATCH EPOXY COUNTERS WITH ATTIC STOCK

ALT #2 - REMOVE EXSTG VINYL FL TILE & RUBBER BASE AT WALLS & CABS; INSTALL NEW

DRYING RACK ETR - INSTALL CP/CI PEGS AT (4) OPENINGS

REMOVE EXSTG & INSTALL NEW DOORS AT LOCS WHERE VENEER IS PEELING (TYP 5 LOCS); SPECIES TO MATCH EXSTG (OAK, VIF). SALV & REINSTALL HDW

6 A501 REF PHOTO
SCALE NTS



SHELVES ETR; PROTECT

REMOVE, SALV & RETURN TO OWNER ALL WALL MTDED SHELVES & BRACKETS; PATCH & PT WALLS PER SCHED

REMOVE REAGENT SHELF, CHASE, SEISMIC LIPS & TURRETS. PROTECT ETR LAB GAS LINES & POWER; COORD WITH MEP

REMOVE & SALV PORTIONS OF EPOXY COUNTERTOP AS NEEDED FOR TROUGH & BASE CAB REMOVAL; PROTECT FOR REINSTALLATION

REMOVE WOODEN VERT CHASE & ASSOCIATED TRIM AT WEST END OF BENCH

REMOVE ABANDONED ACID VENT LINES; GLASS PIPES ENCLOSED BY SS JACKET; COORD W MECH

REMOVE, SALV & RETURN TO OWNER WALL MTDED CORK BOARDS; PATCH & PT

5 A501 BENCH A REF PHOTO
SCALE NTS



REMOVE BRACING & TEMPORARILY SUPPORT ETR DRYING RACK; PATCH HOLES IN EPOXY AS NEEDED

DRYING RACK ETR; PROTECT

REMOVE REAGENT SHELF, CHASE, SEISMIC LIPS & TURRETS. PROTECT ETR LAB GAS LINES & POWER; COORD WITH MEP

REMOVE, SALV & RETURN TO OWNER WALL MTDED WHITE BOARD; PATCH & PT WALL

WIREMOLD ETR; DO NOT PT

SINK BASE CAB ETR; PT-2 ALKYD ENAMEL

4 A501 BENCH C REF PHOTO
SCALE NTS



REMOVE, SALV & RETURN TO OWNER ALL WALL MTDED SHELVES & BRACKETS; PATCH & PT WALLS PER SCHED

REMOVE ABANDONED WIRE

ALT #1 - APPROX LOC OF NEW CLG MTDED LOCAL CP/CI EXHAUST ARM WITH MTDING BRACKET. CONNECT TO NEW EXHAUST DUCT ABOVE ACT; COORD W MECH

REMOVE EXSTG & INSTALL NEW CORK AT DIVIDERS

FUME HOOD ETR; PT-2 ALKYD ENAMEL

WIREMOLD ETR; DO NOT PT

REMOVE, SALV & RELOCATE CYLINDER RESTRAINTS TO SIDE OF FUME HOOD; REUSE EXSTG HOLES. PATCH & PT WALL PER SCHED

REMOVE SHELF AND RETURN TO OWNER

ALT #2 - REMOVE EXSTG VINYL FL TILE & RUBBER WALL BASE & INSTALL NEW PER SCHED

3 A501 REF PHOTO
SCALE NTS

2 A501 REF PHOTO
SCALE NTS

COORD W ELEC FOR REMOVAL OF EXSTG LIGHT & FOR INSTALLATION OF NEW LIGHT UNDER SHELF AT ALL LOW WORK STATIONS

DEMO: REMOVE CORK AT VERT WOODEN DIVIDERS ETR; BOTH SIDES OF BENCHES. PROTECT WOODEN DIVIDERS & PATCH AS NEEDED IN PREPARATION FOR NEW CORK

RENO: PROVIDE & INSTALL NEW CORK AT VERT DIVIDERS WHERE OLD CORK IS REMOVED, FULL WIDTH & HT PER SCHED

REMOVE DRAWER AT DESK TO CREATE ADA COMPLIANT KNEEHOLE; PROTECT ADJ BASE CAB ETR.

PATCH &/OR REPAIR BASE CABINETS ETR AND FILLER PANEL (ALL SIDES) AS NEEDED AT DRAWER REMOVAL

1 A501 REF PHOTO
SCALE NTS

STATE OF MISSOURI
Emily M. Johnson
A-2020011136
ARCHITECT

ARCHITECT -
EMILY M. JOHNSON
MO# A-2020011136

Emily M. Johnson
Digitally signed by Emily M. Johnson
Date: 2021.09.07 22:36:22 -05'00'

The Professional Architects seal and signature applies only to the material and information shown on this sheet. All drawings, instruments, or other documents prepared by this architect, and to be considered prepared by this architect, and this architect expressly disclaims any and all responsibility for such documents or documents not exhibiting this seal.

This Document is intended to be signed digitally. If no digital signature is attached to this PDF, the signature shall not be considered a certified document.

09/13/21	ISSUED FOR CONSTRUCTION	
	DRAWN BY: EH	CHECKED BY: EJ

CAMPUS FACILITIES
Planning, Design, & Construction
Design Services
UNIVERSITY OF MISSOURI

SCHWEITZER HALL
COLUMBIA, BOONE COUNTY, MISSOURI 65211
RENOVATE LAB 213
REFERENCE PHOTOS

PROJECT NUMBER
CP211261

SHEET
A501